ubuntu配置samba共享数据(免密码)

参考: https://blog.csdn.net/giangwei1212/article/details/68923558

1. 安装samba: 一共有两个应用

```
sudo apt-get install samba
sudo apt-get install smbclient
```

修改samba 的配置文件

打开配置文件: vim /etc/samba/smb.conf

```
[share]
comment=samba ##这个是说明,随意填
path=/home
public=yes
writable = yes
create mask=0775
directory mask=0775
available = yes
browseable = yes
forceuser=root
forcegroup=root
```

3、重启samba

```
sudo /etc/init.d/samba restart
```